
DI-718Bx “Save Default Setup” and “Open Reference File” Calibration Settings Error

On this Page

[Symptoms](#)

[Cause](#)

[Resolution](#)

[Delete TPDATAQ.ini and re-install WinDaq software](#)

[Applies To](#)

Symptoms

- After selecting **Save Default Setup** from the **File** pull-down menu and restarting WINDAQ, calibration settings are not retained.
- Selecting **Open Reference File** from the **File** pull-down menu and choosing a previously recorded data file does not transfer calibration settings into WINDAQ.

Cause

Software bug.

Resolution

To resolve these issues follow the steps below.

Delete TPDATAQ.ini and re-install WINDAQ software

1. Locate TPDATAQ.INI in the WINDOWS directory, and delete it.
2. Download the latest installation from: <http://www.dataq.com/support/downloads/new710.exe>.
3. Run the new installation software that you just downloaded, installing the application over top of the existing installation.

The software should now operate properly.

Applies To

All DI-718Bx Devices.